





QUICKSTART GUIDE




- 1. First select the desired preset location: Fave-1 (blue) or Fave-2 (orange) by pushing the lower-right knob.
- 2. Start finding the desired sound by browsing the speaker/cab type (upper-left knob) and adjusting the mic placement (lower-right knob).
- 3. Store the current setting by holding down the lower-right knob until the corresponding Fave LED flashes 3x.

STEREO WIDTH ENHANCEMENT ON HEADPHONE OUT

Cabzeus Mono employs a simple stereo-enhancement technique for the headphone output, where a short delay is applied to the right-channel audio. The amount of delay is adjustable from 0 ms to 30 ms. To make the adjustment: turn the lower-right knob while holding it down - we call this operation twisting the knob. The delay setting is saved in the preset as well.



QUICKSTART GUIDE



Speakers Selection

	Speakers	Modelled after :
GUITAR	VNTAGE30 - 10 " - 12 "	CELESTION Vintage 30
	VNTAGE C - 10 " - 12 "	JENSEN Vintage Ceramic C10R & C12R
	LEGEND B - 10 " - 12 "	EMINENCE Legend B810
	VNTAGE60 - 10 " - 12 "	CELESTION Vintage 60
	PATRIOTS - 10 " - 12"	EMINENCE Patriots series
	GRENBACK - 10 " - 12 "	CELESTION Greenback
	FANO A60 - 10" - 12"	FANE A60
	FANO A90 - 10" - 12"	FANE A90
BASS	PULSER - 10 " - 15 "	CELESTION Pulse10 and Pulse15
	BASSLITE - 10" - 15"	EMINENCE Basslite S20
	PUNCHY - 10" - 15"	JENSEN Punch BP 10-150 & BP 12-250
	SMOOTH - 10" - 15"	JENSEN Smooth BS 10N-250A & BS 1N5-350A

Got to our website www.gfisystem.com for full user manual and warranty registeration.